

HOW TO SET UP AND USE Bevcomm TV on a Roku Device

My Bevcomm TV:

Login: _____

Passphrase: _____

Using Your Roku Remote:

- Use **UP, DOWN, LEFT, RIGHT** to navigate.
- Press **OK** to select.
- Press **HOME** to return to the Roku home screen.
- Press **BACK** to go to the previous screen.

Setting Up Your Roku Device:

1. Connect your Roku device to your TV's **HDMI port** and plug in the power adapter.
2. Use the USB cable to power the Roku Device.
3. Put batteries in your Roku remote.
4. Turn on your TV and switch to the correct HDMI input.
5. Follow the on-screen instructions to connect to Wi-Fi and install updates.
6. Sign in with your Roku account as instructed.

Adding Bevcomm TV to Your Roku Device:

1. From the Roku home screen, navigate to **Streaming Store**, press **OK**.
2. Scroll to **Search**, press **OK**.
3. Search for **Bevcomm TV**.
4. Highlight the app, press **OK**.
5. Select **Add App**, press **OK**.

Accessing Bevcomm TV on Your Roku Device:

1. On the Roku home screen, highlight **Bevcomm TV**.
2. Press **OK** to open.
3. On first launch, you'll need to enter your Initial Login and Passphrase. (Contact our office if you haven't received these.)



To access Bevcomm TV through your mobile device, download our app!

My Roku Account:

Username: _____

Password: _____

Wi-Fi Network:

SSID: _____

Password: _____

Watching Bevcomm TV

Accessing the Program Guide:

- From the Roku home screen, highlight the Bevcomm TV app and press **OK**.
- While watching a program, press **BACK** to open the guide.

Navigating in the Program Guide and Watching a Channel:

- Use the **UP/DOWN** to scroll through programs.
- Press ***** to jump to desired channel.
- Press **OK** for program details (Watch, Record, Search).
- Press **BACK** inside the guide to open the **Tab Bar** (For You, Guide, Recordings, Search, Settings).
- Press **REWIND/FAST FORWARD** to navigate up/down in guide.

Channel Surfing:

- While watching TV, press **UP/DOWN** to jump to the next/previous channel.

Restart Program from Beginning:

- Press **RIGHT** during a program, choose **Restart this program**, and press **OK**. (Some programs may not support Restart).

Rewind, Fast Forward, or Pause Live TV:

- Use the **FAST FORWARD** and **REWIND** to move through recorded content.
- Press **PLAY/PAUSE** to pause or resume live TV.

Quick Guide:

- Press **LEFT** while watching to open a list of recently watched channels.
- Scroll **UP/DOWN** to scroll through previous channels.
- Press **OK** to switch channels.

Closed Captioning:

- Press ***** while watching program, use **RIGHT** to turn captions **ON/OFF**.

Recordings

Making a Recording:

- In the guide, press ***** or select program and choose **Record**. Press **OK** on one of the following:
 - Series - New Only**
 - Series - All**
 - One-Time**

Accessing and Managing Recordings:

- Go to the **Tab Bar**, then **Recordings**. Categories include:
 - Current Recordings**: Watch/delete recordings.
 - Future/Upcoming Recordings**: Adjust start/stop times.
 - Series Rules**: Manage episode limits, new/all episodes, and recording times.
 - Recently Deleted**: Restore deleted recordings.
- Use remote arrows to switch between categories.

Search

Accessing the Search Feature:

- Go to **Tab Bar** and press **Search**.
- Type the name of a program, highlight a program and press **OK**.
- Choose **Watch** if it's airing, or **Record** to schedule it.

Settings

Adding a New Device (Up to 20 allowed):

- Go to the **Settings** option in the **Tab Bar**, press **Manage Account**.
- Scroll to **Add Device** and press **OK**.
- A new login and passphrase will be generated.
- Use these credentials on the TV by following the **Accessing Bevcomm TV** steps above.